

Pop-up Lighting




Powerspot 200 Powerspot 300



Powerspot 400 Powerspot 500



Powerspot 600 Powerspot 900



Powerspot 950 Powerspot 1000

A range of pop-up lighting options to fit any environment, from subtle low voltage spotlights to high impact mains halogen and fluorescents.



Powerspot 1200

Features & benefits

- All lights are supplied with a 3m lead with fitted plug and lamp
- Choice of UK or Euro style plug
- Polypropylene lighting case and Fabric lighting bags available
- Replacement lamps available
- Selection to suit all budgets

Light fitting options


- Pole fittings for locating light on Pop-up Node
- Universal, Moulded or Claw fittings for locating light on Pop-up scissors

Light	Description	Code	Colour	Fitting Options	Usage	Fitting Code
Powerspot 200	50w 240V GU10 Lamp	PS200	Silver	Xpress Claw Fitting	Xpress, Xpress Jumbo	us.xpress
				Quick Claw Fitting	Quick, Quick Jumbo	us.scissor
				Pole Fitting	All Systems except Spider	us.pole.b
Powerspot 300	50w 240v GU10 Lamp	PS300	Black or Silver	Xpress Claw Fitting	Xpress, Xpress Jumbo	us.xpress
				Quick Claw Fitting	Quick, Quick Jumbo	us.scissor
				Pole Fitting	All Systems except Spider	us.pole.b
Powerspot 400	35w LV MR11 Lamp	PS400	Silver	Xpress Claw Fitting	Xpress, Xpress Jumbo	us.xpress
				Quick Claw Fitting	Quick, Quick Jumbo	us.scissor
				Pole Fitting	All Systems except Spider	us.pole.b
Powerspot 500	50w LV MR16 Lamp	PS500	Black or Silver	Xpress Claw Fitting	Xpress, Xpress Jumbo	us.xpress
				Quick Claw Fitting	Quick, Quick Jumbo	us.scissor
				Pole Fitting	All Systems except Spider	us.pole.b
Powerspot 600	50w LV Halogen Lamp	PS600	Black or Silver	Xpress Claw Fitting	Xpress, Xpress Jumbo	us.xpress
				Quick Claw Fitting	Quick, Quick Jumbo	us.scissor
				Pole Fitting	All Systems except Spider	us.pole.b
Powerspot 900	150w 240V Halogen Lamp	PS900	Black/ Clear	Moulded Fitting	All Systems except Spider	With light
				Moulded Pole Fitting	All Systems except Spider	us.pole-b-plastic
Powerspot 950	150w 240V Halogen Lamp	PS950	Black	Pop-up universal moulded Fitting	All Systems except Quick or Xpress Tower	With light
Powerspot 1000	200w 240V Halogen Lamp	PS1000	Black	Xpress Moulded Fitting	Xpress, Xpress Jumbo, Spider	us.scis38d
				Quick Moulded Fitting	Quick, Quick Jumbo, Spider	us.scissorplastic
				Moulded Pole Fitting	All Systems except Spider	us.pole-b-plastic
Powerspot 1200	20w 240V Fluorescent T4	PS1200	White Frame	Integral clip	All Systems except Spider	With light


NB All light fittings are in black unless otherwise stated.

Assembly Instructions

Pole Fitting / Moulded Pole fitting



Place node fitting into the top node void. Fasten to the popup frame using a #6 x 1" screw.



Slide the moulded pole fitting into the node fitting.

PS950 Quick Universal Fitting



With the front of popup frame facing you, place the light fitting to the right of where the scissor tubes cross. Insert the fitting between the top tube and the one beneath.

PS950 Xpress Universal Fitting



With the front of popup frame facing you, place the light fitting to the left of where the scissor tubes cross. Insert the fitting between the top tube and the one beneath.

Quick Claw Fitting



Place the light fitting where the scissor tubes cross. Position the smaller hook under the top tube and the longer hook under the lower tube.

Xpress Claw Fitting



Place the light fitting where the scissor tubes cross. Position the smaller hook under the top tube and the longer hook under the lower tube.

PS900 Quick Moulded Fitting




Slide the fitting onto the light. With the front of popup frame facing you, place the light fitting where the scissor tubes cross. Insert the fitting between the top tube and the one beneath.

PS900 Xpress Moulded Fitting



Slide the fitting onto the light. With the front of popup frame facing you, place the light fitting where the scissor tubes cross. Insert the fitting between the top tube and the one beneath.

Quick Moulded Fitting



Slide the fitting onto the light. With the front of popup frame facing you, place the light fitting where the scissor tubes cross. Insert the fitting between the top tube and the one beneath.

Xpress Moulded Fitting



Slide the fitting onto the light. With the front of popup frame facing you, place the light fitting where the scissor tubes cross. Insert the fitting between the top tube and the one beneath.